

**WARNING**

Causes serious eye irritation.
Causes skin irritation.

Wash hands thoroughly after handling.
Wear protective gloves and eye protection.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing.

If eye irritation persists: Get medical advice.

IF ON SKIN: Wash with plenty of water.

If skin irritation occurs: Get medical advice.

Take off contaminated clothing and wash it before reuse.

Batch: 000000

Net Content: 0 Litres

**ATTENTION**

Provoque une sévère irritation des yeux.
Provoque une irritation cutanée.

Se laver les mains soigneusement après manipulation.
Porter des gants de protection et équipement de protection des yeux.

EN CAS DE CONTACT AVEC LES YEUX:

Rincer avec précaution à l'eau pendant plusieurs minutes. Enlever les lentilles de contact si la victime en porte et si elles peuvent être facilement enlevées. Continuer à rincer.

Si l'irritation des yeux persiste: Demander un avis médical.

EN CAS DE CONTACT AVEC LA PEAU:

Laver abondamment à l'eau.
En cas d'irritation cutanée: Demander un avis médical.
Enlever les vêtements contaminés et les laver avant réutilisation.

PAC-200

ALL PURPOSE CLEANER

This is a very concentrated liquid pressure wash detergent designed to be used in power washers with hot or cold water. It combines the cleaning properties of powders with the convenience of a liquid cleaner. It contains solvents and emulsifiers for degreasing and loosening of heavy soil deposits and detergents to remove all dirt and road film leaving a clean surface. This product is safe to use on all painted surfaces, metal parts, plastic, concrete and wood.

DIRECTIONS: For cleaning most surfaces with pressure wash equipment, dilute 1:40 to 1:100 with water. Best results are obtained by using hot water. Wet the entire surface to be cleaned with wash solution. Clean each section thoroughly. Rinse with cold water and allow to drain.

For heavy cleaning of equipment, engines, etc., dilute 1:10 with hot water. Leave on surface for approximately 5 minutes. Rinse with warm water and allow to drain dry.

Food equipment and food contact surfaces should be rinsed clean with potable water after use. Avoid contamination of food during application and storage.

CONTAINS: surfactant, water conditioner, butyl cellosolve